



AMERICAN WIRELESS ALARM, INC.

4450 Northgate Ct
Sarasota, FL 34234

Ademco Lynx

Away Mode:

Press the **AWAY button** for 2-3 seconds. This mode will arm the motion and give you a 60 second exit delay/45 second entry delay.

Stay Mode:

When staying home but you want the alarm to be on, press the **STAY button** for 2-3 seconds. This will turn off the motion but still give you a delay on your entry/exit doors.

Disarmed Mode:

Enter your **4 digit code** then press **OFF**.

Reset Alarm:

Enter your **4 digit code** then **OFF** and your **4 digit code** then **OFF** a second time.

Change Master Code:

****Do Not Pause between numbers**** Enter your **4 digit master code** (default = 1234) then **802** and your **new 4 digit code** then your **new 4 digit code** a second time. If accepted, you will hear a beep.

Change User Code(s):

****Do Not Pause between numbers**** Enter your **4 digit master code** then **8** plus the user number (**03-06**) and your **new 4 digit code**. If accepted, you will hear a beep.

Any Questions Call:
866-823-5279